


# Test Tag G - IBM PCjr Internal Modem Test

If, while running the IBM PCjr Internal Modem Test, you wish to discontinue the test and return to the First IBM PCjr Test Menu Screen, press Fn, then press Break.

1

Your screen looks like this.



It takes almost three minutes to test your modem. After your IBM PCjr has finished testing your modem, the First IBM PCjr Test Menu Screen appears with a message under Test Tag "G". The meaning of that message is shown below:

- \* Your modem is operating correctly. Go to Step 3.
- A Your IBM PCjr does not know you have a Modem attached. Make sure your Internal Modem is not connected to your telephone jack. If it is not connected to your telephone jack, have your IBM PCjr serviced. See "Service Information" in this section.
- B Have your IBM PCjr serviced. See "Service Information" in this section.
- C Your Modem detected a dial tone. If your telephone line is connected to your Modem, disconnect it and go to "Running the IBM PCjr Tests" in this section and select the Modem test again. If your telephone line is not connected to your Modem, have your IBM PCjr serviced. See "Service Information" in this section.

- D** Have your IBM PCjr serviced. See "Service Information" in this section.

**3**

Do you want to run another test?

- YES -** Go to "Running the IBM PCjr Tests" in this section.
- NO -** If you have a diskette drive installed, you may run the "Exploring the IBM PCjr" diskette at this time. If you have run the "Exploring the IBM PCjr" diskette before, you may continue normal operations.

**Notes:**

# Test Tag A - IBM Personal Computer Graphics Printer Test

Before beginning the IBM Personal Computer Graphics Printer Test, make sure your Printer power is turned on.

Your screen remains blank during the Printer Test.

1 Does your Printer begin to print?

YES - Go to Step 2.

NO - Go to Step 3.

Does your printout match the sample below?

```

!"#$%&'()*+,-./
0123456789:;<=>?
@ABCDEFGHIJKLMNO
PQRSTUVWXYZ[\]^_
`abcdefghijklmnopqrstuvwxyz{|}~
!"#$%&'()*+,-./
0123456789:;<=>?
@ABCDEFGHIJKLMNO
PQRSTUVWXYZ[\]^_
`abcdefghijklmnopqrstuvwxyz{|}~
!"#$%&'()*+,-./
aióúññáâäåçèéêëìíîï«»
ΣπρσςΣβΓσζαρεθΩ
□ □ □ □

```

**YES -** Go to Step 3.

**NO -** Go to "Graphics Printer Checkout Procedure" in this section.

When the Second IBM PCjr Test Menu Screen reappears there is a message under Test Tag "A". The meaning of this message is shown below:

- \*** You have completed the Graphics Printer Test. Go to Step 4.
- A** Have your IBM PCjr serviced. See "Service Information" in this section.
- B** Your printer is out of paper. Load paper into your printer properly and go to "Running the IBM PCjr Tests" in this section, select the Graphics Printer Test again. If the paper is loaded and the Graphics Printer Test results in a "B", have your printer serviced. See "Service Information" in this section.

**C**        Go to "IBM Graphics  
Printer Checkout  
Procedure" in this section

**D or E**    Have your IBM PCjr  
serviced. See "Service  
Information" in this  
section.

**4**

Do you want to run another test?

**YES -**    Go to "Running the IBM  
PCjr Tests" in this section.

**NO -**     If you have a diskette drive  
installed, you may run the  
"Exploring the IBM PCjr"  
diskette at this time. If you  
have run the "Exploring the  
IBM PCjr" diskette before,  
you may continue normal  
operations.



# IBM Graphics Printer Check Out Procedure



## CAUTION

When you are asked to remove the printer signal cable, always turn your printer power and your IBM PCjr power off.

Any help you will need to run the Printer Self-Test or load supplies can be found in your IBM Graphics Printer Installation and Operating Instructions inserted in Section 5 "The IBM PCjr Options."

You may lose information if the Printer power is turned off while you are sending information to the printer from your IBM PCjr.


- 1 Turn your IBM PCjr power and your printer power off.



Testing

**2**

**Disconnect the printer cable from the printer.**



**3**

**Plug your printer power cord into a working wall outlet.**

**4**

**Run the Printer Self-Test. If you need help to do this, go to the IBM Graphics Printer Installation and Operating Instructions in Section 5, "The IBM PCjr Options."**

**Did the Printer Self-Test run without failures?**

**YES - Go to Step 10.**

**NO - Go to Step 5.**

- 5 Be sure that your ribbon is installed properly.
- 6 Be sure that your paper forms are inserted properly.
- 7 Be sure that there is nothing in the way that will keep your paper forms from moving.
- 8 Be sure that the tractors are adjusted properly.

If you need help with any of the above, see the IBM Graphics Printer Installation and Operating Instructions in Section 5, "The IBM PCjr Options."

Did you find any problems while following the above steps?

**YES -** Correct the problem. Go to Step 11.

**NO -** Go to Step 9.

9

Does your printer have any of the following problems?

- Your printer beeps even though the paper is installed properly.
- Your printer does not beep when it is out of paper.
- Some of the lights on the control panel do not work.
- Your printer continues to print when it is out of paper.

**YES -** Have your printer serviced.  
See "Service Information"  
in this section.

**NO -** Go to Step 10.

10

Your printer is also controlled by program commands from the system unit. If you have a printer problem only while running a particular program, check the program thoroughly for commands being sent to the printer that may cause it to produce undesired results.

Do you want to run the Graphics  
Printer Test again?

**YES -** Go to "Running the IBM  
PCjr Tests" in this section.

**NO -** If you have a diskette drive  
installed, you may run the  
"Exploring the IBM PCjr"  
diskette at this time. If you  
have run the " Exploring  
the IBM PCjr diskette  
before, you may continue  
normal operations.

**Notes:**

