


# Test Tag 8 - 80 Column Display Test

**Note:** This test applies to color and non-color displays. Remember, because colors vary, the colors in this book may not match the colors on your screen.

If, while running the 80CD TEST, you wish to discontinue the test and return to the First IBM PCjr Test Menu Screen, press Fn, then press Break.

- 1** Do the shapes of the blocks and figures on your screen match those in the example below?




**YES -** Press




and go to Step 2.

**NO -** Have your IBM PCjr serviced. See "Service Information" in this section.

Does your screen match the example below?



YES - Press



and go to Step 3.

NO - Have your IBM PCjr serviced. See "Service Information" in this section.


Does your screen match the example below?

```

40 x 20
**H23456789: < >0ABCEFGHI
**H23456789: < >0ABCEFGHI
**H23456789: < >0ABCEFGHI
**H23456789: < >0ABCEFGHI
**H23456789: < >0ABCEFGHI
**H23456789: < >0ABCEFGHI
**H23456789: < >0ABCEFGHI
**H23456789: < >0ABCEFGHI
**H23456789: < >0ABCEFGHI
**H23456789: < >0ABCEFGHI
**H23456789: < >0ABCEFGHI
**H23456789: < >0ABCEFGHI
**H23456789: < >0ABCEFGHI
**H23456789: < >0ABCEFGHI
**H23456789: < >0ABCEFGHI
**H23456789: < >0ABCEFGHI
**H23456789: < >0ABCEFGHI
**H23456789: < >0ABCEFGHI
**H23456789: < >0ABCEFGHI
**H23456789: < >0ABCEFGHI

```


YES - Press




and go to Step 4.

NO - Have your IBM PCjr serviced. See "Service Information" in this section.

Do the shapes of the blocks and figures on the screen match those in the example below?



**YES -** Press




and go to Step 5.


**NO -** Have your IBM PCjr serviced. See "Service Information" in this section.

5

Do the shapes of the blocks and figures on the screen match the example below?




YES - Press



and go to Step 6.

NO - Have your IBM PCjr serviced. See "Service Information" in this section.

Do the shapes of the blocks and figures on the screen match the example below?




**YES -** Press



and go to Step 7.

**NO -** Have your IBM PCjr serviced. See "Service Information" in this section.




## Testing


## 80CD Test 6-61



Does your screen match the figure below?



YES - Press




and go to Step 9.


NO - Have your IBM PCjr serviced. See "Service Information" in this section.



Do the shapes of the blocks and figures on the screen match the example below?




YES - Press




and go to Step 10.

NO - Have your IBM PCjr serviced. See "Service Information" in this section.

Do the shapes of the blocks and figures on the screen match the example below?




YES - Press




and go to Step 11.

NO - Have your IBM PCjr serviced. See "Service Information" in this section.

Do the shapes of the blocks and figures on the screen match the example below?




YES - Press




and go to Step 12.

NO - Have your IBM PCjr serviced. See "Service Information" in this section.




Press



Another screen appears. Continue to press the Insert key, each time displaying the next screen, until the screen is filled with sevens (7).

Did you reach the screen filled with sevens?

YES - Press



and go to Step 13.

**NO -** Have your IBM PCjr serviced. See "Service Information" in this section.

Some blank screens appear briefly and then the First IBM PCjr Test Menu Screen appears. A message appears under the Test Tag "8". The meaning of the message is shown below:

- \* You have completed the 80CD TEST. Go to Step 14.
- A You do not have enough memory installed to run the 80CD TEST. This test requires the 64KB memory and display expansion option installed in your IBM PCjr. If you have the 64KB memory and display expansion option installed, have your IBM PCjr serviced. See "Service Information" in this section. If you do not have the 64KB memory and display expansion option installed go to Step 14.
- B Have your IBM PCjr serviced. See "Service Information" in this section.
- ? You have interrupted the 80CD TEST before it was complete by pressing Fn and then pressing Break. Go to Step 14.

Do you want to run another test?

- YES -** Go to the "Running the IBM PC<sub>jr</sub> Tests" in this section.
- NO** If you have a diskette drive installed, you may run the "Exploring the IBM PC<sub>jr</sub>" diskette at this time. If you have run the "Exploring the IBM PC<sub>jr</sub>" diskette before, you may continue normal operations.